

Bass: 1G 2D 3A 4E C Ukulele: 1A 2E 3C 4G **Features** HD LCD display. Customized high sensitive built-in censor (piezo). Calibration, memory backup and auto-power-off functions. Metal Clip and ball joint for maximum durability and flexible angle of view. Installing the battery When the battery charge is low, the LCD will become dim. Please replace the battery as soon as possible. 1.Pay attention to polarity when replacing battery. NOTE: 2.Remove the battery if the product will not be used for a long period. Tuning Guide Lower than standard pitch Higher than Standard Pitc

Guitar: 1E 2B 3G 4D 5A 6E

Specifications Tuning Range: A_a (27.50 Hz)~C_a (4186 Hz) This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Reference Pitch : A4=430Hz~450Hz (1 Hz steps) Tuning modes: Chromatic, Guitar, Bass, Ukulele(C) Tuning Precision: +/-1 cent more of the following measures: Power Supply: CR2032 lithium battery x 1 · Recrient or relocate the receiving antenna. Dimension: 50(L) x 25(W) x 48(H)mm Weight: 32g Precautions Environment 1.Do NOT use the tuner in high temperature, or high humidity, or subzero environments. 2.Do NOT use the tuner in the direct sunlight. Please do NOT disassemble the tuner by yourself. Please keep this manual for future reference. Accessories Owner's manual 3V(CR2032) Lithium battery Cherub Technology Co., Ltd. Technology Co. Ltd. * Specification may change without notice

Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. The equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications, However, there is no guarantee that interference will not occur in a naticular installation. If this equipment does cause harmful interference to radio or belevision recention which can be determined by turning the equipment off and on the user is encouraged to try to correct the interference by one or

THE FCC REGULATION WARNING (for U.S.A.)

. Increase the separation between the equipment and receiver

 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. . Consult the dealer or an experienced radio/TV technician for help.

All Rights Reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by



www.nuxefx.com Made in China